

AGM IR Flashlight Guide

Flashlight Operation

To activate a sensor for the first time or to cause its status LED to illuminate, point the IR flashlight at the window of a sensor unit and press the flashlight button for approximately one second. After the sensor LED illuminates, release the flashlight button.

The flashlight button can either be pressed directly with one's finger, or, for better visibility and for easier operation with gloves, position the flashlight clip over the button so that pressing down on the clip depresses the flashlight button.



Figure 1 : Standard Clip Position



Figure 2 : Clip Positioned On Flashlight Button

Flashlight Charging

To charge the IR flashlight, open the flashlight charging port cover and connect the flashlight to a 1A (5W) or greater power supply with a standard Micro USB cable. The flashlight fully charges in approximately five hours.

A fully charged flashlight has a life of approximately 8 hours at 25°C.

Note: do not operate the flashlight while it is charging.

Flashlight Button LED Reference

LED Action	Status
Off	Not transmitting/ Charging complete
Solid Green	Transmitting
Blinking Red	Transmitting, Low Battery
Solid Red	Charging

Operation Specifications

Operating Temperature range:

-30°C to +55°C

Charging Temperature range:

0°C to +45°C